



POS.	CODE	PIECES	DESCRIPTION
1	R18202060	1	DOOR
2	R18202010	1	INNER DOOR PANEL
3	R71201500	1	INNER DOOR GLASS
4	R58001760	2	INNER GLASS SOLID HINGE
5	R58001770	2	INNER GLASS HINGE PIN
6	R58001780	2	INNER GLASS CATCH KIT
7	R11401340	1	TOP "C" PROFILE
8	R11401360	1	LOWER "C" PROFILE
9	R18203910	1	LOWER SUPPORT GLASS
10	R18203920	1	TOP SUPPORT GLASS
11	R18404500	1	LOWER DOOR HINGE
12	R58002520	1	LOWER HINGE PIN
13	R11200560	1	UPPER DOOR HINGE
14	R58002150	1	HINGE PIN
15	R58004050	2	NUT FOR UPPER DOOR HINGE
16	R10401710	1	WASHER FOR UPPER DOOR HINGE
17	R70050100	6	GLASS SILICON SPACERS
18	R70044650	1	GLASS GASKET
19	R66110320	1	DOOR LAMPS CABLE SET
20	R11401440	1	LAMP COVER
21	R71500150	1	GLASS LAMP

POS.	CODE	PIECES	DESCRIPTION
22	R70044200	1	LAMP GASKET
23	R11401450	1	GLASS HOLDER LAMP FLANGE
24	R65270020	1	LIGHT 20W 12V G4
25	R65270450	1	LIGHT SOCKET
26	R65260750	1	LAMPS CONTACT BLOCK
27	R66110300	1	LAMPS CONTACT CABLE SET
28	R69015000	1	DOOR HANDLE ASSEMBLY
29	R09200230	1	DOOR HANDLE
30	R10100110	1	PRONG FLANGE
31	R58003240	1	DOOR HANDLE BUTTON ROD
32	R58004270	1	DOOR HANDLE SPACER
33	R58004830	1	RING NUT M18x1
34	R58005050	1	DOOR HANDLE PRONG
35	R58005340	1	DOOR HANDLE LOWER INSULATION WASHER
36	R58005350	1	DOOR HANDLE UPPER INSULATION WASHER
37	R61620012	1	DOOR HANDLE CATCH SPRING
38	R61620041	1	DOOR HANDLE BUTTON SPRING
39	R69031190	1	DOOR HANDLE PUSH BUTTON
40	R58002160	1	DOOR HANDLE PRONG PIN
41	R18202020	1	DOOR HANDLE PRONG COUPLER

